

**description**

DETECT DOOR is a PUZZLE compatible wireless doorbell that connects to the existing doorbell installation and replaces the standard push button outside the door.

**application**

When someone pushes the DETECT DOOR it transmits signals to one or more of the following PUZZLE receivers:

- CALL sound alerting device
- FLASH light alerting device
- POCKETVIB wireless vibrator
- WAKE alarm and alerting device
- LOOP teleloop amplifier
- BEAM infrared system
- LINK AUX adapter

**key features**

DETECT DOOR can be adjusted to 16 different personal codes allowing up to 16 DETECT DOOR installations to operate close to each other. For homes with several doorbell locations up to four DETECT DOOR systems can operate simultaneously with different signal patterns. DETECT DOOR runs on a single replaceable Lithium battery lasting approximately 10 years.

**design**

DETECT DOOR is composed of hard ABS plastic and designed for outdoor operation in all weather conditions.

**specifications:****wireless doorbell****specifications**

transfer of signals	Transmits by FM (frequency: 433.92 MHz)
personal code	32 possible adjustments
alarm signals	Transmits one out of 4 possible alarm signals
range	Up to 75 metres
battery	1 pcs. Lithium type ½ AA 3.6 V
battery duration	Appr. 10 years (when activated 5 times daily)
size (WxHxD)	38 x 88 x 20 mm / 1,5 x 3,5 x 0,8 in
color	Black/gray or white/gray
material	ABS plastic Silicon sticker