



### Wireless Alerting Transmitter

DETECT is a wireless alerting transmitter that picks up the sounds from a variety of sources (doorbells, telephones, entry phones, smoke detectors, kitchen timers, etc.). These sounds can be easily missed by a person with hearing loss, but they are very important for their safety and quality of life.

DETECT is placed right next to the sound (e.g., doorbell) that the user needs to hear. After the doorbell rings, DETECT's built-in microphone lets the user know by sending a signal to one or more of the following PUZZLE receivers:

- CALL sound alerting device
- FLASH light alerting device
- WAKE alarm and alerting device
- POCKETVIB wireless vibrator
- LOOP teleloop amplifier
- BEAM infrared system
- LINK AUX adapter

One DETECT alerting transmitter per alarm is needed.

### Easy to Distinguish

DETECT has seven different signal patterns, one for each sound source. That way the user can easily identify which alarm has been activated.

### Personal Codes

DETECT can be adjusted to 32 different codes allowing for up to 32 DETECT alerting transmitters to operate within the same apartment house. The code can be changed if necessary, and an unlimited number of DETECTS can be used within the same house/apartment.

### Extra Alarm

DETECT has an input through which an extra alarm can be connected by cable. We recommend that this input is used only when another DETECT cannot be mounted (e.g., if a doorbell and entry phone are placed right next to each other).

### Battery Operated

DETECT runs on one lithium AA battery, which will last approximately 10 years. It has a built-in battery tester so the user can check to see if the battery needs to be changed.

### Technical Data

Special developed microphone:	Detects the alarm signal (sensitivity can be adjusted)
Transfer of signals:	Transmits by FM (frequency: 433.92 MHz)
Personal code:	32 possible adjustments
Alarm signals:	Transmits one out of 7 possible alarm signals
Input:	1 activated by contact closure
Range:	Up to 75 metres
Battery:	1 pcs. Lithium type AA
Battery duration:	Aprr. 10 years (when activated 5 times daily)
Battery test unit:	Yes
Size:	36 x 85 x 110 mm / 1.4 x 3.4 x 4.3 in
Weight:	110 g
Colour:	Black or white
Material:	ABS plastic