



Wireless Vibrator

POCKETVIB is a powerful wireless vibrator which receives alarm signals from the OBSERVER baby alarm and pager as well as from the doorbell, entry phone, telephone, smoke detector etc., using the DETECT alerting transmitter. After POCKETVIB receives an alarm signal it converts it into a vibration to alert the user.

The device must be carried close to the body, either in a pocket or clipped to the user's clothing. It has a range of up to 75 meters (246 feet).

Easy to distinguish

POCKETVIB has seven different vibration patterns, one for each sound source. That way the user can easily identify which alarm has been activated. It also has four differently-coloured lights on the front of the device that will alert the user.

Battery-operated

POCKETVIB runs on three alkaline batteries and has an approximate battery life of one year under normal use (activated five times daily). It has a built-in battery tester so the user will know when the battery needs to be changed.

Technical Data

Vibrations:	7 different vibration patterns
Diode signal:	4 different coloured diodes
Transfer of signals:	Receives by FM (frequency: 433.92 MHz)
Personal code:	32 possible adjustments
Range:	Up to 75 metres
Battery:	3 pcs. Alkaline type LR 1, 1.5 V
Battery duration:	Appr. 1 year (activated up to 5 times a day)
Battery watch:	Yes
Dimensions (HxWxD):	85 x 55 x 23 mm (~ 33.5 x 21.7 x 9.1 in)
Material:	Black ABS plastic